

accuSHRINK I Nx™ (Shrinkage Template & Scale)

INTRODUCTION

Shrinkage is the change in dimensions of any fabrics or garments after laundering or dry-cleaning. To access this dimensional change directly with maximum accuracy accuSHRINK I Nx™ has been developed which meets the specifications of International standards.

EQUIPMENT

accuSHRINK I Nx™ is a specially designed equipment with 8 Calibrated slots spaced at 14 inches for making three bench marks lengthwise & three benchmarks widthwise on fabrics or garments as per international standards. The template & the scale both are completely made of acrylic. The scale is graduated up to 15% for shrinkage & 15% for stretch. The scale & template both are nicely packed in a specially designed carrying case for safety & easy transport.

SALIENT FEATURES

- Specially designed equipment to determine directly the % dimensional change (shrinkage) in all types of fabrics.
- Fine Calibrated Shrinkage Template with eight carrying case 14 Inches Benchmarks.
- Calibrated Scale to Check the Shrinkage directly from 0-15%.
- Even the Stretch can be directly measured up to 15%.
- Two fine tipped Yellow Fabric Markers for accurately marking on the Dark Colored fabric.
- Two fine tipped Black Fabric Markers for accurately marking on the Light Colored Fabric.
- All the items nicely packed in a beautiful Box.
- The innovative carrying case serves as a mobile carrier for instant checking anywhere.
- Supplied with Inspection and Calibration Certificate.

accuSHRINK I Nx™ is supplied complete with below accessories.

Calibrated Marking Template	: 01 No.
Calibrated Scale	: 01 No.
Textile Marking Pen (Two Black & Two Yellow)	: 04 Nos.
Detailed User's Manual	: 01 No.
Fine Carrying Case	: 01 No.
Calibration Certificate (Traceable to NPL)	: 01 No.
Inspection & Conformance Certificate	: 01 No.



TECHNICAL DETAILS

Template length between slot to slot	: 350 mm
Distance of scale between slot to slot	: 350 mm
Max. % Shrinkage to be measured	: 15%
Max. % Stretch to be measured	: 15%
Overall Dimensions Of the template	: 500 x 500 x 3 mm
Overall Dimensions Of the Scale	: 245 x 60 x 5 mm
Net weight of template & scale	: 1 kg (2.2 lbs)

RELATED STANDARDS

ASTMD 2259 – 96
D 2102 – 96
ISO 3759
BS 4931



Corporate Member



An ISO 14001 : 2004 Group
We Care for our Environment !



Member : Bureau of Indian Standards