

# *checkMATE™ (Inspection Table)*

**INTRODUCTION**

Fabric is your major Investment. This constitutes 60% - 70% of the cost of GARMENT, hence it is your most valuable resource. In order to have full control over this precious Investment. Paramount has introduced the most Economical Manual operated Fabric Inspection Machine to check & control any wastage of this valuable input. Better the quality of fabric - Better will be the end product. This is the aim behind developing **checkMATE™** our most economical Fabric Inspection Machine.

**EQUIPMENT**

Paramount **checkMATE™** is designed to inspect fabrics up to 60" Width manually. It can detect minor faults with Bottom & Top illumination Unit. Special fabric tray is provided to keep the loose fabric to inspect. A mechanical length counter is provided to measure the length of fabric inspected.

**SPECIAL FEATURES**

1. Most economical equipment to inspect fabric upto 60 Inch Width.
2. Wide viewing area helps in flawless inspection.
3. Top & Bottom illumination unit.
4. A Special Tray is provided for keeping loose fabric to inspect.
5. Control Panel for Top & Bottom Lights.
6. Special top fabric guide roll helps in easy flow of fabric.
7. A mechanical length counter to measure the length of fabric inspected (Optional).

**checkMATE™ is supplied complete with below accessories.**

Main Unit	: 01 No.
Tray for keeping fabric	: 01 No.
User's Manual	: 01 No.
Calibration Certificate (Traceable to NPL)	: 01 No.
Inspection & Conformance Certificate	: 01 No.

**TECHNICAL DETAILS**

Power Supply	: 220/230 V, 50 Hz, single phase, 50/60 Hz, AC
	Supply
Max. width of fabric can be check	: 60 Inches
Light source	: Top & Bottom
Fabric movement	: Top to Bottom
Overall Dimensions of the unit	: 2100 (L) x 1475 (D) x 1800 (H) mm
	84 (L) x 59 (D) x 72 (H) Inches.
Net Weight of the unit	: 150 Kg. (330 lb)



Paramount®  
 An ISO 9001 : 2000 Group  
 YOUR QUALITY. OUR OBSESSION™