

checkMASTER Basic™

INTRODUCTION

Fabric is your major Investment. This constitutes 60% - 70% of the cost of GARMENT, hence it is your most valuable resource. We are sure you will like to have full control over this Precious Investment. Paramount has introduced in the market an advanced Instrument to check & control any wastage of this valuable input. Better the quality of fabric - Better will be the end product. This is the aim behind developing **checkMASTER Basic™** (An economic Fabric Inspection Machine). You can visually check any defect or fault in the fabric that you have sourced & have full control on your quality norms.

EQUIPMENT

Paramount checkMASTER Basic™ is an economical inspection machine, which completely made of Mild Steel with digital control panel. The specially designed fabric roll stand is provided to load the fabric to be checked. The bottom illumination unit is covered with milky white acrylic, which acts as a viewing area. The top illumination unit is incorporated for proper inspection. Specially designed tray is provided to keep loose fabric for inspection. The exclusive feature of the machine is that it can be operated by foot switch. A mechanical length counter is provided to measure the length of fabric inspected. The control panel is equipped with speed regulator, Forward & Reverse movement switch.

SALIENT FEATURES

- An economical inspection machine to inspect fabric up to 62" width.
- With top rolling device.
- Analog length counter up to five digits for fabric length measurement.
- Digital control panel with foot & continuous operation option.
- With speed control device.
- Reverse & forward fabric movement option.
- Complete with all accessories-tray for keeping loose fabrics, plastic pipes for rolling fabrics etc.
- Supplied with conformance & inspection certificates.

checkMASTER Basic™ is supplied **complete with below accessories.**

Main Unit	: 01 No.
Top Light Fixing Rods	: 02 Nos.
Top Light Unit (either Fixed to the Unit or in Dismantled condition)	: 01 No.
Tray for keeping Fabric	: 01 No.
Fabric Roll Stands	: 02 Nos.
Stainless Steel Rods (For lifting the Rolls)	: 02 Nos.
Plastic Pipes (For making of Rolls)	: 02 Nos.
User's Manual	: 01 No.
Inspection & Conformance Certificate	: 01 No.



TECHNICAL DETAILS

Power Supply	: 220/230 V, 50 Hz, single phase, 50/60 Hz, AC Supply
Motor	: 1/2 HP
Max. width of fabric can be check	: 62 Inch
Light source	: Top & Bottom (both side)
Counter	: Length counter : 0 – 99999 Mtrs. , L/C : 1 m.
Fabric movement	: From Bottom to Top
Dimension Of Main Unit	: Length width height 2100mm 1475m 1800mm 84inch 59inch 72inch
Weight Main Unit	: 150kg (330 lbs)