

Pick Glass - 001

INTRODUCTION

Construction is one of the most important quality parameter in case of woven fabrics. Paramount *Pick Glass 001* is very useful equipment to check fabric construction or Reed & Pick. It can be used for any kind of woven fabrics.

EQUIPMENT

Paramount *Pick Glass 001* is completely made of fibre for its lightweight & long life with one inch by one-inch slot. Specially designed movable metal pointer is incorporated to ease in counting. It has a high-resolution magnifying glass of 8x to view the threads separately in case of fine dense fabrics too. It is supplied in a beautiful pack for risk free storage & look.

SALIENT FEATURES

- A specially designed fine equipment to check the reed /pick of any type of woven fabrics conveniently & accurately.
- Latest model with modern aesthetics.
- Light weight for mobility.
- With 8X resolution magnifier for sharp image of fabrics.)
- Inbuilt one by one scale with pointer for accurate counting.
- Smooth, precision-engineered component for exceptional performance.
- Fibre body for lightweight & durability.

TECHNICAL DETAILS

Slot dimension	: One inch By One inch
Weight	: 50gms (0.11 lbs)
Dimension: including box.	: 75(L) x, 55(W) x, 35(H) mm
	2.9(L) x, 2.1(W) x, 1.3(H) inch



**AATCC
CORPORATE MEMBER**



Patron Member



**Member Bureau of
Indian Standards**