

**swatchCUTTER 300™**  
**(Fabric Sampling (Pinking) Machine)**

**INTRODUCTION**

PARAMOUNT swatchCUTTER 300™ is an accurate & convenient Equipment for preparing swatches with pinking edges in multiple layers to a depth of 30 mm (1.2") and width of 300 mm (12").

**EQUIPMENT**

PARAMOUNT swatchCUTTER 300™ is a user friendly versatile Swatch Cutting Machine for making swatches upto 300mm (12") wide quickly & conveniently. The specially designed Equipment can cut swatches in multiple layers up to a depth of 30mm. It can make samples out of any type of fabric (woven/knitted or non woven) with the special imported Italian scissor. The equipment is mounted on a strong & sturdy table for ease in operation. The sample sizes can conveniently determined by the graduated screen fixed on the fabric guide bar. The cutting area is fully protected by a transparent acrylic sheet for safety, which also helps the operator to view the cutting operation. The specially designed cutting board is provided to support the sample to cut & long life of the blade. A specially designed long handle is attached with the equipment for smooth cutting with minimum operator fatigue. The equipment is meticulously finished in blue & grey paint to give a gorgeous look.

**SALIENT FEATURES**

- Specially designed equipment to prepare swatches of different size & design.
- Sample up to 300mm width & any length can be cut.
- Depth of the sample up to 30mm can easily be cut.
- A sturdy Wooden stand to keep the equipment stable during operation.
- Smooth precision-engineered components for exceptional performance.
- Pinking blade tip gives excellent look of swatches prepared.
- A Calibrated scale is provided to prepare sample of different sizes as required.
- Supplied with inspection certificates.

**swatchCUTTER 300™ (Normal) is supplied complete with below accessories.**

Main Unit	: 01 No.
Sturdy Table (Fitted or Dismantled Position)	: 01 No.
Special Cutting Mat/ Board (Made in Italy)	: 01 No.
Double End Spanner – (13-13)	: 01 No.
Double End Spanner - (10-10)	: 01 No.
This User's Manual	: 01 No.
Inspection & Conformance Certificate	: 01 No.



**TECHNICAL DETAILS**

Cutting Width	: 300 mm
Cutting Height	: 20 – 30 mm
Dimension of the cutting pad	: 300 x 300 mm (±2 mm)
Graduated Scale	: 32 Cm. on left side & 27 Cm. on right side; From the "0" position (cut position) L/C : 1 mm
Dimension of the Instrument (Including Table)	: 700 (L) x 600 (W) x 1295 (H) mm 28" (W) x 24" (D) x 52" (H) Inch.
Dimension of the Instrument (Excluding Table)	: 600 (L) x 600 (W) x 560 (H) mm 24" (W) x 24" (D) x 22.5" (H) Inch.
Net Weight of the Instrument	: 32 Kg. (71 lb)
Net Weight of the Table	: 21 Kg. (46 lb)



**AATCC**  
CORPORATE MEMBER



**Patron Member**



**Member Bureau of Indian Standards**